

## Necked Tower Bolt:

This product is to be used for recessed doors & gates.

1. Position bolt assembly on door/gate. Secure with screws provided.
2. Align fixing plate onto the door/gate frame & secure with screws provided.
3. Drill hole through center of fixing plate for bolt recess.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.