

## Tower Bolt / Oval Padbolt / Brenton Padbolt / Spring Loaded Animal Bolt / Antique Straightdoor Bolt:

1. Position bolt assembly on door/gate. Secure with screws provided.
2. Ensuring that the bolt is in the engaged position, align the staple on the door/gate frame. Mark holes and secure staple with the screws provided.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.